



1. ACC Fuse 10A
2. Main Fuse 30A
3. Ignition Relay
4. Headlight Fuse 10A
5. Headlight Relay
6. Starter Circuit Relay
7. Taillight Fuse 15A
8. Ignition Fuse 10A
9. Turn Signal Relay Fuse 10A

1. Front Brake Light Switch
2. Engine Stop Switch Spark Plug
3. Starter Button
4. Headlight Switch
5. Ignition Coil

1. Coolant Temperature Sensor
2. Fuel Gauge
3. Rear Brake Light Switch
4. Ignition Coil
5. Starter Button

1. Horn Button
2. Turn Signal Switch
3. Dimmer Switch
4. Passing Button
5. Starter Lockout Switch

1. Left Handlebar Switches
1. Horn Button
2. Turn Signal Switch
3. Dimmer Switch
4. Passing Button
5. Starter Lockout Switch

Digital Clock Meter Light 12V3W

Sidestand Switch

Pickup Coil

Alternator

Oil Pressure Switch

Neutral Switch

Starter Relay

Starter Motor

IC Ignitor

12V15Ah Battery

Accessory Leads

Rear Light

License Light

Rear Light

IC Ignitor

Starter Relay

Starter Motor

IC Ignitor

12V15Ah Battery

Accessory Leads

Oil Pressure Switch

Neutral Switch

Alternator

Digital Clock Meter Light 12V3W