


<http://mes.gtr.free.fr>

<http://mes.gtr.free.fr>



<http://mes.gtr.free.fr>

<http://mes.gtr.free.fr>

Color Code	
BK	Black
BL	Blue
BR	Brown
CH	Chocolate
DG	Dark Green
G	Green
GY	Gray
LB	Light Blue
LG	Light Green
O	Orange
P	Pink
PU	Purple
R	Red
W	White
Y	Yellow

LEFT HANDLEBAR SWITCH CONNECTIONS									
Horn Button	Turn Signal Switch	Dimmer Switch	Passing Button	Starter Lockout Switch					
Color	BK/WBK/Y	Color	G O GY	Color	R/BK/BL/Y/R/Y	Color	BR R/BK	Color	BK/Y BK BK/R
ON (Push)	R	HI	ON (Push)	Clutch Lever					
	N			Released					
	L	LO		Pulled In					

IGNITION SWITCH CONNECTIONS				
Ignition	Battery	Ignition	Tail 1	Tail 2
Color	BR W	GY	BL	R
ON	ON	ON	ON	ON
P (PARK)				

RIGHT HANDLEBAR SWITCH CONNECTIONS									
Headlight Switch	Front Brake Light Switch	Engine Stop Switch	Starter Button						
Color	BL/Y BL R/BL/R/W	Color	BK BK	Color	Y/R R	Color	BK/R/BK/R		
ON	Released	OFF	ON (Push)						
OFF	Pulled In	RUN	OFF						